

# Kit ECN/2 ~ 1lt

*Nik & Trick*  
*Services Photographiques*

motion picture negative film process

This kit contains:

- Prebath 1lt ready to use and re-use
- Chemical concentrates to make 1lt each of reusable: Developer, Stop Bath, Bleach and Fixer
- Chemical concentrate to make up 2lt of reusable final rinse / stabiliser

## Safety & handling instructions:

We advise you to use common sense and to take every precaution when handling photographic chemistry with this kit we prefer you to wear protective gloves & eye protection. Wash hands thoroughly after use, ALWAYS rinse eyes immediately and seek medical advice should chemistry get in them.

For further information refer to MSDS or contact Bellini Foto: [info@bellinifoto.it](mailto:info@bellinifoto.it) or Nik & Trick Photo Services

## Mixing instructions:

**PREBATH** - 1lt Ready to use

**DEVELOPER** – To 700ml of water add Part A, then Part B & Part C. Add water to make final 1lt volume

**STOP** – To 600ml of water add the concentrate. Add water to make final 1lt volume

**BLEACH** – To 460ml of water add the Bleach Concentrate, add more water to make to final volume

**FIXER** – To 790ml of water add the Fix Concentrate, add more water to make to final volume

**FINAL RINSE** – To 1900ml water add the Rinse Concentrate. Make up to 2lt final volume.

## Process:

Processing Step	Temperature °C	Time
<b>PREBATH</b>	27.0 ± 1.0	10"
<b>Rem-Jet</b>	27.0-38.0	
<b>DEVELOPER</b>	41.1 ± 0.1	3'00"
<b>STOP</b>	27.0-38.0	30"
<b>WASH</b>	27.0-38.0	30"
<b>BLEACH</b>	27.0 ± 1.0	3'00"
<b>WASH</b>	27.0-38.0	30"
<b>FIXER</b>	38.0 ± 1.0	2'00"
<b>WASH</b>	27.0-38.0	2'00"
<b>FINAL RINSE</b>	27.0–38.0	10"

With reference to the processing guide overleaf  
this is how we get rid of Remjet...



Add enough pre-bath to submerge all films  
in your tank...we soak for 45 seconds



Wash wash and wash, until water runs  
clean and clear ~ Use gentle agitation.



Follow preprocessing guide for steps:  
Develop, Stop, Bleach & Fix

DO NOT STABILISE YET!



Remove films from tank one at a time.  
Wash them under running water and  
use new soft cotton wool to wipe away  
any remaining traces of remjet.

NON-EMULSION SIDE ONLY!



Stabilise in as much Final Rinse as you like for  
about 30 seconds then hang to dry.

© 2019 Nik & Trick Photo Services Ltd ~ [www.NTphotoworks.com](http://www.NTphotoworks.com)

Nik & Trick note: Do bear in mind that in stills photography we are not using these films as they are designed to be used you may therefore find the occasional variation or odd remnant of Remjet. If your scanner has Digital Ice then this usually cleans that away from the final image, an image that may require some amount of post processing to really get the best